
Electronic Stability Program (ESP) System (1)
SD588-1
HOT IN ON OR START
See Power Distribution (SD110-15)
F10 10A MODULE 3
See Passenger Compartment Fuse Details (SD120-3)
SMART JUNCTION BOX
P.63/69 C.80-3/5/6/7
IPS CONTROL MODULE
C-CAN
High
Low
Parking Brake Switch
I/P-C
I/P-M
I/P-K
I/P-N
UMC
M01
S_GND
INSTRUMENT CLUSTER
P.58 C.10-1
ABS
ESP
ESP OFF
BRAKE
DBC (GREEN/RED)
MICOM
C-CAN TRANSCEIVER
M-CAN TRANSCEIVER
GM02
P.122
M/T, A/T(LHD)
A/T(RHD)
MF21
P.45
EF11
P.44
EM11
P.44
F15-L(M/T)
F15-P(A/T-LHD)
E37(A/T-RHD)
PARKING BRAKE SWITCH
P.75/181 C.20-13/40-5
E24(LHD)
E25(RHD)
BRAKE FLUID LEVEL SENSOR
P.29 C.20-10/11
See Data Link Details (SD200-4)
See Ground Distribution (SD130-3)
JOINT CONNECTOR
JM01
M43
ON/START Input
Ground
STEERING ANGLE SENSOR
W/O MDPS
P.178 C.10-17
GM03
P.57
P.121 C.82-4
See Data Link Details (SD200-4)(SD200-6)(SD200-7)
See Back-Up Lamps (SD926-3)
M/T
E19
ESP CONTROL MODULE
P.32 C.20-9
Back-Up Signal
ESP UNIT
M13-A(Europe)
M70-B(M/T & Except Europe)
A/V & NAVIGATION HEAD UNIT
P.51 C.10-8/24
GE03
P.39