

Anti-Lock Brake System (ABS) (4)
SD587-4
DSL (D4HA/D4HB)
HOT WITH ENGINE CONTROL RELAY ON
See Power Distribution (SD110-11) (SD110-12)
EMS BOX P.37 C.81-1
F47 10A
HOT AT ALL TIMES
E/R FUSE & RELAY BOX
F27 10A
BRAKE SWITCH
HOT AT ALL TIMES
See Power Distribution (SD110-16)
SMART JUNCTION BOX P.63 C.80-3
F8 15A
STOP LAMP
Ⓐ: Close with Brake Pedal Depressed
Ⓑ: Open with Brake Pedal Depressed
E/R-A
0.5P
0.5L
I/P-C
0.85G
E41
STOP LAMP SWITCH P.42 C.20-14
0.5Y
EM11 P.44
0.5L/B
0.85R
See Stop Lamps (SD927-2)
M42
Stop Lamp
Stop Lamp Switch
B+
IPS
INTERNAL CONTROL
INPUT CIRCUIT
STOP SIGNAL ELECTRONIC MODULE P.62 C.10-16
Stop Lamp Signal
Ground
0.3R/B
0.3R/O
0.5B
EM21 P.45
E100-K(D4HB)
E100-KL(D4HA)
ECM P.36 C.20-2/3
M10-B
SMART KEY CONTROL MODULE P.150 C.10-7
E18
Brake Light Switch
ABS UNIT
ABS CONTROL MODULE P.32 C.20-9
GM02 P.122